RZ2 Retrofit — Ballast Reversing Relay Wiring (per pump)


Option A: replace the OEM reversing rocker. Repeat this circuit 3× — PORT, STARBOARD, CENTER.

Legend

- +12 V (red, fused)
- Ground / motor return (black)
- ESP32 GPIO signal (blue)

Per-pump color code (paint the relay & land label)

PORT — K1 FILL / K2 EMPTY	STARBOARD — K3 / K4	CENTER — K5 / K6



Print at A3 or Letter landscape. Verify GPIO mapping against docs/BRIDGE_PINOUT.md before landing wires.